


dorien

TRICHEF 3 IN 1 COOKER

INSTRUCTION MANUAL

MODEL: DMA-35



General Safety Precautions


1. Please read this instruction booklet carefully before operating the appliance.
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
3. Children should be supervised to ensure that they do not play with the appliance.
4. This appliance is intended for household use only.
5. Do not use the appliance outdoors or on wet surfaces.
6. Always handle the plug and appliance with dry hands.
7. Do not immerse the main body, power cord, or plug in water or any other liquid to avoid the risk of electric shock or short circuit.
8. Ensure all food ingredients remain inside the glass jug to prevent contact with internal heating elements, which may cause malfunction or fire hazard.
9. Do not operate the appliance if any parts are damaged, missing, or defective.
10. Do not use the appliance if it has been dropped or shows signs of damage.
11. Do not leave the appliance unattended while it is connected to the mains power supply.
12. Always unplug the appliance before cleaning or maintenance. Allow at least 30 minutes for cooling after use.
13. Ensure that the voltage rating corresponds to the rating label of the appliance.

14. Use only accessories supplied or recommended by the manufacturer.
15. If the power cord is damaged, it must be replaced by a qualified service agent to avoid hazards.
16. Keep the power cord and appliance away from heat sources and sharp edges.
17. Always place the appliance on a stable, flat, and heat-resistant surface.
18. Maintain a minimum clearance of 20 cm around the appliance during operation.
19. Do not block the air inlet or outlet during use.
20. Hot steam is released during operation. Keep hands and face away from the steam outlet.
21. Exercise caution when removing the glass jug after cooking, as hot air and steam may escape.
22. The appliance surfaces may become hot during operation. Avoid direct contact.
23. Do not move the appliance while it is in operation.
24. Avoid touching hot surfaces to prevent burns or injury.
25. Do not cover the appliance during operation.
26. Switch off the appliance and unplug it from the mains before disconnecting. Do not pull the power cord.
27. Store the appliance in a dry place away from direct sunlight and high humidity.
28. Always unplug the appliance after use and before cleaning or maintenance.
29. Ensure the appliance has completely cooled before cleaning or storage.
30. Keep the appliance away from flammable materials during operation.

Specification

MODEL:	DMA-35
POWER:	220-240V~
RATED VOLTAGE:	1200-1400W
FREQUENCY:	50/60Hz
CAPACITY:	3L
TEMPERATURE RANGE:	AIR FRYER:40-230°C / GRILL:80—250°C

Parts Identification



1.	Knob	8.	Grill Plate
2.	Heating Head	9.	Low Rack
3.	Detachable Glass Jug	10.	Temperature Button
4.	Jug Handle	11.	Digital Display
5.	Digital control Dial	12.	Menu Mode
6.	Air Outlet (Behind head)	13.	Timer Button
7.	Release Button	14.	Start/ Pause Button

Before First Use

1. Remove all packaging materials from the appliance.
2. Wash the glass jug, low rack, and grill plate with warm water, mild detergent, and a soft cloth or non-abrasive sponge. Rinse thoroughly.
3. Do not use abrasive cleaners, steel wool, or scouring pads, as they may damage the appliance surfaces.
4. Dry all parts thoroughly before use.
5. Wipe the interior and exterior of the appliance with a soft damp cloth, then dry completely.

Operating Instructions

I. AIR FRYER FUNCTION

1. Connect the appliance to a suitable mains power outlet.
2. Carefully pull the glass jug out of the appliance using the handle.
3. Place the low rack into the jug and arrange the food evenly on the rack.
4. Reinsert the glass jug into the appliance. Ensure that the upper locking point of the jug handle is properly aligned with the center opening of the head rim. A beep will sound and the display will show “—”, indicating that the appliance has entered Standby Mode.
5. Press the Start/Pause Button to enter the menu mode. The display will show “P01”. The appliance is equipped with 16 preset cooking programs.

6. Rotate the control dial to select the desired preset program (P01–P16).
7. Press the Temperature Button and set the desired temperature (40°C–230°C). Turn the control dial clockwise to increase or counterclockwise to decrease the temperature in 5°C increments.
8. Press the Timer Button and set the desired cooking time (1–60 minutes). Turn the control dial clockwise to increase or counterclockwise to decrease the time in 1-minute increments.
9. Press the Start/Pause Button to start cooking. The timer will begin counting down.

Menu Mode

Display	Menu	Default Temperature	Default Time
P01	Air Fryer	220°C	20 min
P02	Chicken Wings	230°C	12 min
P03	Chips	210°C	10 min
P04	Steak	230°C	8 min
P05	Fish	180°C	15 min
P06	Vegetables	180°C	12 min
P07	Skewers	200°C	10 min
P08	Chicken	220°C	25 min
P09	Shrimp	180°C	15 min
P10	Bread	200°C	4 min
P11	Cake	160°C	25 min
P12	Pizza	180°C	10 min
P13	Biscuits	180°C	12 min
P14	Dried Fruits	60°C	8 h
P15	Keep Warm	80°C	12 min
P16	Defrost	80°C	10 min

During Cooking

- Press the Start/Pause Button once to pause cooking.
- Press the Start/Pause Button again to resume cooking.
- Temperature and cooking time may be adjusted during operation.
- To cancel cooking and return to Standby Mode, press and hold the Start/Pause Button.

Completion of Cooking

1. When the cooking cycle is complete, an audible signal will sound and the display will show "End".
2. Carefully remove the glass jug and place it on a stable, heat-resistant surface.
3. Check whether the food has reached the desired level of cooking.
4. If additional cooking is required, reinsert the jug and set the desired cooking time.

Note: For optimum cooking performance, preheat the appliance for at least 3 minutes before placing food inside.

II. GRILL FUNCTION

1. Press and hold the Release Button, then rotate the heating head upwards into the grill position.
2. Install the grill plate by ensuring that both support feet of the grill plate are securely inserted into the corresponding holes on the top rim.

Temperature and Time Adjustment

In Grill Function, the temperature can be adjusted from **80°C to 250°C**.

- Turn the control dial clockwise to increase the temperature.
- Turn the control dial counterclockwise to decrease the temperature.
- Temperature is adjusted in **5°C increments**.

The cooking time can be adjusted from **1 to 60 minutes**.

- Turn the control dial clockwise to increase the time.
- Turn the control dial counterclockwise to decrease the time.
- Time is adjusted in **1-minute increments**.

Safety Protection Function

For safety purposes, the appliance is equipped with a microswitch safety interlock.

- During Air Fryer operation, removing the glass jug will automatically stop the heating and cooking process.
- During Grill operation, removing the grill plate assembly will automatically stop the heating and cooking process.
- Once the glass jug or grill assembly is correctly reinstalled, the appliance will automatically resume operation according to the previously selected settings.

Note:

1. The preset menu mode is not available in Grill Function.
2. The adjustable temperature range for Grill function is 80°C to 250°C.

RECOMMENDED COOKING SETTINGS

The table below provides recommended settings for various food types.

Note: The cooking times provided are for reference only. Actual cooking time may vary depending on the quantity, size, shape, and thickness of the food.

Food Type	Temperature	Time
Thin Frozen Chips	220°C	12-16 min
Thick Frozen Chips	220°C	12-20 min
Homemade Chips	220°C	15-20 min
Potato Wedges	180°C	18-30 min
Potato Cubes	180°C	12-18 min
Cheese Sticks	150°C	8-10 min
Chicken Nuggets	180°C	6-10 min
Fish Sticks	180°C	6-10 min
Pork Chop	180°C	10-14 min
Hamburger	180°C	7-14 min
Chicken Drumsticks	220°C	15-20 min
Chicken Breast	220°C	10-15 min

Care and Cleaning

1. Switch off the appliance and disconnect it from the power supply.
2. Remove the plug from the wall outlet and allow the appliance to cool completely.

Tip: Removing the glass jug will help the appliance cool down more quickly.

3. Wipe the exterior surfaces with a soft damp cloth. Do not use abrasive cleaners, solvents, or scouring materials, as they may damage the appliance.
4. Wash the glass jug with warm soapy water and a soft non-abrasive sponge. Rinse and dry thoroughly.
5. Clean the interior surfaces with a damp cloth or sponge. Do not use abrasive cleaners or harsh cleaning agents, as they may damage the appliance.
6. Ensure all parts are clean and completely dry before reassembling and storing the appliance.

Troubleshooting

Problem	Possible Cause	Solution
The appliance does not operate.	The appliance is not connected to the power supply.	Ensure the plug is properly inserted into a suitable power outlet.
	The cooking time has not been set.	Set the required cooking time and start the appliance.
Food is not cooked properly.	Too much food has been placed in the glass jug.	Reduce the quantity of food and cook in smaller batches for more even results.
	The selected cooking temperature is too low.	Increase the cooking temperature.
	The cooking time is too short.	Increase the cooking time.
White smoke is emitted from the appliance.	Food with a high fat content is being cooked.	This is normal. Excess grease may produce white smoke during cooking. Clean the glass jug after use.
Fresh chips are not crispy.	The potato pieces were not dried sufficiently before cooking.	Dry the potato pieces thoroughly and lightly coat them with oil before cooking to achieve a crispier result.

Note: If the problem persists after performing the above checks, discontinue use and contact an authorized service center for assistance.

Distributed by:
SEGA APPLIANCES (M) SDN. BHD.
76, Jalan Tasik Prima 2/2, Taman Tasik Prima,
47150 Puchong, Selangor, Malaysia
Tel: +60-14-2895236